

FLASH BAR 150

DMX CONTROL TABLE



1-CH Mode					
CH1	Auto Programs	000	-	005	Auto Programs off
		006	-	054	Auto Program 1
		055	-	103	Auto Program 2
		104	-	152	Auto Program 3
		153	-	201	Auto Program 4
		202	-	255	Auto Program 5

2-CH Mode					
CH1	Master Dimmer	000	-	255	Master Dimmer 0% - 100%
CH2	Strobe	000	-	005	Strobe off
		006	-	255	Strobe Speed (slow to fast)

3-CH Mode					
CH1	Master Dimmer	000	-	255	Master Dimmer 0% - 100%
CH2	Strobe	000	-	005	Strobe off
		006	-	255	Strobe Speed (slow to fast)
CH3	Duration	000	-	255	Flash duration (0ms to 510ms)

5-CH Mode					
CH1	Master Dimmer	000	-	255	Master Dimmer 0% - 100%
CH2	Strobe	000	-	005	Strobe off
		006	-	255	Strobe Speed (slow to fast)
CH3	Duration	000	-	255	Flash duration (0ms to 510ms)
CH4	Auto Programs (override CH1-3)	000	-	005	Auto Programs off
		006	-	054	Auto Program 1
		055	-	103	Auto Program 2
		104	-	152	Auto Program 3
		153	-	201	Auto Program 4
		202	-	250	Auto Program 5
CH5		251	-	255	Sound Mode
		000	-	255	Auto Speed (slow to fast) / Sound Sensitivity

15-CH Mode					
CH1	Light Control	000	-	255	Dimmer LED 1
CH2		000	-	255	Dimmer LED 2
CH3		000	-	255	Dimmer LED 3
CH4		000	-	255	Dimmer LED 4
CH5		000	-	255	Dimmer LED 5
CH6		000	-	255	Dimmer LED 6
CH7		000	-	255	Dimmer LED 7
CH8		000	-	255	Dimmer LED 8
CH9		000	-	255	Dimmer LED 9
CH10		000	-	255	Dimmer LED 10
CH11		000	-	255	Dimmer LED 11
CH12		000	-	255	Dimmer LED 12
CH13		000	-	255	Dimmer LED 13
CH14		000	-	255	Dimmer LED 14
CH15		000	-	255	Dimmer LED 15

20-CH Mode					
CH1	Master Dimmer	000	-	255	Master Dimmer 0% - 100%
CH2	Strobe	000	-	005	Strobe off
		006	-	255	Strobe Speed (slow to fast)
CH3	Duration	000	-	255	Flash duration (0ms to 510ms)
CH4	Auto Programs	000	-	005	Auto Programs off
		006	-	054	Auto Program 1
		055	-	103	Auto Program 2
		104	-	152	Auto Program 3
		153	-	201	Auto Program 4
		202	-	250	Auto Program 5
		251	-	255	Sound Mode
CH5		000	-	255	Auto Speed (slow to fast) / Sound Sensitivity
CH6	Light Control	000	-	255	Dimmer LED 1
CH7		000	-	255	Dimmer LED 2
CH8		000	-	255	Dimmer LED 3
CH9		000	-	255	Dimmer LED 4
CH10		000	-	255	Dimmer LED 5
CH11		000	-	255	Dimmer LED 6
CH12		000	-	255	Dimmer LED 7
CH13		000	-	255	Dimmer LED 8
CH14		000	-	255	Dimmer LED 9
CH15		000	-	255	Dimmer LED 10
CH16		000	-	255	Dimmer LED 11
CH17		000	-	255	Dimmer LED 12
CH18		000	-	255	Dimmer LED 13
CH19		000	-	255	Dimmer LED 14
CH20		000	-	255	Dimmer LED 15