

# PAR 64 CAN

## DMX CONTROL TABLE



4-CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000-255	RED (0-100%)
CH2	000-255	GREEN (0-100%)
CH3	000-255	BLUE (0-100%)
CH4	000-255	MASTER DIMMER (0-100%)

6-CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000-255	RED (0-100%)
CH2	000-255	GREEN (0-100%)
CH3	000-255	BLUE (0-100%)
CH4	000-255	MASTER DIMMER (0-100%)
CH5	000-016 017-255	No function Strobe speed - Jumping/Fading speed - Microphone sensitivity (refers to channel 6)
CH6	000-031 032-095 096-159 160-223 224-255	No function Colour fading Colour jumping RGB Colour jumping 7 colour Sound control