

PAR 64 CAN

DMX CONTROL TABLE



2-CH Mode					
CH1	Dimmer & Strobe	000	-	240	Master Dimmer 0-100%
		241	-	255	Strobe slow -> fast
CH2	Colour Macro	000	-	004	Colour off
		005	-	010	Red
		011	-	015	Green
		016	-	020	Blue
		021	-	025	Amber
		026	-	030	RG
		031	-	035	GB
		036	-	040	RB
		041	-	045	RA
		046	-	050	GA
		051	-	055	BA
		056	-	060	RGB
		061	-	065	RGA
		066	-	070	RBA
		071	-	075	GBA
		076	-	080	RGBA
		081	-	150	Colour Jumping slow -> fast
151	-	255	Colour Fading slow -> fast		

3-CH Mode					
CH1	Red	000	-	255	0% to 100%
CH2	Green	000	-	255	0% to 100%
CH3	Blue	000	-	255	0% to 100%

4-CH Mode					
CH1	Red	000	-	255	0% to 100%
CH2	Green	000	-	255	0% to 100%
CH3	Blue	000	-	255	0% to 100%
CH4	Amber	000	-	255	0% to 100%

7-CH Mode					
CH1	Dimmer	000	-	255	Master Dimmer 0% to 100%
CH2	Strobe	000	-	000	Strobe open
		001	-	255	Strobe slow -> fast
CH3	Red	000	-	255	0% to 100%
CH4	Green	000	-	255	0% to 100%
CH5	Blue	000	-	255	0% to 100%
CH6	Amber	000	-	255	0% to 100%

CH7	Colour Macro (override RGBA)	000	-	004	Colour off
		005	-	010	Red
		011	-	015	Green
		016	-	020	Blue
		021	-	025	Amber
		026	-	030	RG
		031	-	035	GB
		036	-	040	RB
		041	-	045	RA
		046	-	050	GA
		051	-	055	BA
		056	-	060	RGB
		061	-	065	RGA
		066	-	070	RBA
		071	-	075	GBA
		076	-	080	RGBA
		081	-	150	Colour Jumping slow -> fast
151	-	255	Colour Fading slow -> fast		