

STUDIO MINI PAR COB 30W

DMX CONTROL TABLE



2-CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Master dimmer (0 - 100%)
CH2	000 - 255	Colour macro
	000 - 031	Blackout
	032 - 063	Red
	064 - 095	Green
	096 - 127	Blue
	128 - 159	Yellow
	160 - 191	Cyan
	192 - 223	Magenta
	224 - 255	White
	000 - 255	Colour (change) macro

3-CHANNEL MODE 1		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Master dimmer (0 - 100%)
CH2	000 - 255	Stroboscope (rate 0 - 100%)
CH3	000 - 004	Blackout
	005 - 080	Colour macro (red, green, blue, yellow, cyan, magenta, white)
	081 - 150	Colour change (rate)
	151 - 220	Colour blending (rate)
	221 - 255	Music control (microphone sensitivity)

3-CHANNEL MODE 2		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Red (0 - 100%)
CH2	000 - 255	Green (0 - 100%)
CH3	000 - 255	Blue (0 - 100%)

6-CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Master dimmer (0 - 100%)
CH2	000 - 255	Stroboscope (rate 0 - 100%)
CH3	000 - 255	Red (0 - 100%)
CH4	000 - 255	Green (0 - 100%)
CH5	000 - 255	Blue (0 - 100%)
CH6	000 - 004	Blackout
	005 - 080	Colour macro (red, green, blue, yellow, cyan, magenta, white)
	081 - 150	Colour change (rate)
	151 - 220	Colour blending (rate)
	221 - 255	Music control (microphone sensitivity)