

# STUDIO MINI PAR TRI 3W

## DMX CONTROL TABLE



| KANAL | WERT   | FUNKTION  |
|-------|--|---|
| CH1   | 000 - 255  | Master-Dimmer (0-100%)                                    |
| CH2   | 000 - 255  | RED (0-100%)  |
| CH3   | 000 - 255  | GREEN (0-100%)  |
| CH4   | 000 - 255  | BLUE (0-100%)   |
| CH5   | 000 - 004<br>005 - 084<br>085 - 169<br>170 - 255 | No function<br>Colour micro<br>Colour jump<br>Colour fade |
| CH6   | 000 - 255  | Strobe  |