

## FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FREQUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE

## WIRELESS MICROPHONES

### LDWSEC016B5

584 - 607 MHz

No.	Frequency MHz
1	584.400MHz
2	587.500MHz
3	589.575MHz
4	591.050MHz
5	593.425MHz
6	595.200MHz
7	598.450MHz
8	599.650MHz
9	601.275MHz
10	603.775MHz
11	605.500MHz
12	606.750MHz
13	586.025MHz
14	590.525MHz
15	594.150MHz
16	602.450MHz

### LDWSEC016B6

655 - 679 MHz

No.	Frequency MHz
1	655.200 MHz
2	656.675 MHz
3	658.500 MHz
4	660.050 MHz
5	661.500 MHz
6	662.900 MHz
7	664.425 MHz
8	666.500 MHz
9	667.800 MHz
10	668.225 MHz
11	670.800 MHz
12	672.275 MHz
13	673.725 MHz
14	675.075 MHz
15	676.500 MHz
16	678.600 MHz

### LDWSEC016

863 - 865 MHz

No.	Frequency MHz
1	863.100MHz
2	863.900MHz
3	864.500MHz
4	864.900MHz
5	863.200MHz
6	863.300MHz
7	863.400MHz
8	863.500MHz
9	863.600MHz
10	863.700MHz
11	863.800MHz
12	864.000MHz
13	864.100MHz
14	864.200MHz
15	864.300MHz
16	864.400MHz